


Thermo Top Heater Series Smart Controller

Quick Set-Up Guide



- 1 Menu Name
- 2 Menu Symbols
- 3 Time Setting Activated
- 4 Time
- 5 On / Off Button
- 6 Control Knob



Timer



Heating



Settings

Initial Start-Up


When the Control unit is connected for the first time, a message about the Setting/Configuration of the heater is displayed.




Press the control knob and the On/Off Button simultaneously for 3 seconds



Select your Heater
Press the Control Knob




Select the current Day
Press the Control Knob



Select the current Time - turn the Control Knob clockwise to select Hour, press the Control Knob to confirm, then turn the Control Knob clockwise again to select the Minutes, press the Control Knob to set.


If your heater was not selected correctly at Initial Start-Up a Manual Reset is required.

Press the On/Off Button to go to the Main Menu Screen and follow the following steps.




Select the symbol "Settings"

Press the Control Knob




The "Quick Start" menu is displayed

Turn the Control Knob clockwise 10 times until "Reset" is displayed




Select "Reset" by pressing the Control Knob




Press the Control Knob to confirm.

The Control Knob is now restarted

During the restart of the Control Knob, an Hourglass will quickly appear 

Press the Control Knob and the On/Off Button simultaneously for 3 seconds


The Control is now ready for use.



Select your Heater (Note: PHEC System is displayed as TT - Z/C/E HS)


Press the Control Knob

Operation



Select "Heating"

Press the Control Knob



Press the Control Knob to select continuous (infinite) running.

(OR To program a Timer at this point turn the Control Knob clockwise to select the time from 10 minutes to 2 hours).



Continuous (Infinite) Running has been selected




PHEC System Heater Smart Controller

Timer Programming

It is possible to program the Timer Setting 7 days in advance. The heater switches on automatically at the programmed time. Up to 3 time settings per day can be set, with a total of 21 time settings for the week.

Before the timer can be activated, make sure that the:


- Time and current day of the week are set,
- Heater is switched off
- "Timer" symbol has been selected in the main menu



Press the Control Knob


"Add Timer" screen is displayed

Press the Control Knob in order to add a new timer



Turn the Control Knob to select chosen "Day"

Press the Control Knob to confirm selection




Turn the Control Knob to choose the desired Switch On time (Hour)

Press the Control Knob to confirm

Turn the Control Knob again to choose the Minutes

Press the Control Knob to confirm




Turn the Control Knob to choose the desired Switch OFF time (Hour)


Press the Control Knob to confirm

Turn the Control Knob again to choose the Minutes


Press the Control Knob to confirm



Select the "Heating" operation mode from the Main Menu screen



The programmed timer is saved and shown on the display



Press the Control Knob to activate the programmed time

"Activate" message will appear on the display

Repeat the process to add timers (3 timer settings per day, 21 per week)